



# Installation Procedures for Apollo C-Strap

*C-Strap Installation 1*





Before making any holes into your fins review this presentation, if you have any questions please use the following information to contact:

**Thomas Kepler**

**317-872-2522 or [mscdiver@aol.com](mailto:mscdiver@aol.com)**



## Tools Required:

Screwdriver

Side Cutters

Dremel Tool

Markers

along with Bio-Fins  
and Set of C-Straps



**Safety Goggles  
should always  
be worn.**



## Dremel Tool

Requires a cutting head such as one pictured at right.

Be aware when cutting holes that material may be hot, make several attempts at cutting through.





XS – S – M Fins  
require the  
Medium Spring  
Strap

L – LL Fins  
require the  
Large Spring  
Strap



**Note: This sizing may be different,  
depending upon boot type.**



Remove strap



Remove clip



Cut clip lug flush



Draw a line along mold knit line through lug.

Place spring holder base on top of lug aligning radius of holder to lug outline.



Then align spring end of base holder over the knit line which you drew on the fin as shown to get proper angle.



Now mark hole placement using your marker

Hole placement should line up on your knit line marking as shown



You are now ready to cut holes using your Dremel Tool.

Make several attempts at cutting through, do not complete in one attempt.



After cutting holes, install mount for strap holder by pushing through the holes from the inside of the fin pocket



If mount sticks up above both bottom and top spring holder due to a thin fin pocket, install rubber pad under spring holder base.



Place spring holder base on mount



Caution: Note proper way to attach spring onto mount of strap holder



Place flush side of spring down on mount



Place top spring holder onto mount



Place stainless top cover onto mount and insert two stainless screws and tighten, always check screws prior to diving



Repeat installation of  
second side of fin



**Enjoy your  
new straps!**

